CARE AND CLEANING

- After use and before cleaning, remove the mains plug from the wall socket. Let the grill cool in open position.
- Never immerse the appliance in water. You may wipe it clean with a damp cloth or sponge and then dry it with a dry cloth.
- Should any filling be difficult to remove, pour a little cooking oil onto the cooking plate and wipe off after 5 minutes when the filling is softened.
- Do not remove any remaining burnt particles with a hard (metal) object, as this would damaged the non-stick coating.
- Do not clean the inside or outside with any abrasive scouring pad or steel wool as this will damage the finish.

Look-In®
by LAMACOM

MANUEL D'UTILISATION
SANDWICH TOASTER GRAND MODEL

INSTRUCTION MANUAL
BIG SANDWICH MAKER

SCHEMA ET DESCRIPTION DE L'ARTICLE

1. Voyants lumineux de control
2. Grilles chauffantes anti-adhérentes
3. Poignée d'ouverture et de fermeture
4. Câble d'alimentation et support de rangement

CARACTERISTIQUES TECHNIQUES

Tension / Puissance : 220V-240V ~ 1400W

CONSIGNES DE SECURITE

- Avant de brancher l'appareil, s'assurer que le voltage de la source d'alimentation correspond bien à celui indiqué sur la plaque signalétique

4. Keep the grill in the closed position to allow the appliance to pre-heat for about 5 minutes. When the green pilot light goes out, the appliance is ready for use.
5. Fully open the top grill and place the food in the bottom section.
6. Fill the grill by pressing the food into the cooking plate.
7. Carefully close the two parts of the grill together. Do not force shut. Steam will be ejected from between the cooking plates while doing this and care must be taken to ensure that fingers do not come into contact with same.
8. Lock the two halves with the clip while toasting is taking place. During toasting the pilot light will cycle on and off while the thermostat keeps the grill at the right temperature. Your food will be toasted in 2-3 minutes or longer to suit your taste.
9. Open the grill and take the food from the cooking plate using a plastic or wooden ustensils for the non-stick coating.
10. Close the lid to preserve the heat until ready to toast your next dish. Prepare further dishes if required while one is cooking.
11. After use, remove the mains plug from the wall socket.

The cooking plates sears outside food surface and cooks meats, poultry, seafood, vegetables. Quickly prepare hot snacks, breakfast, lunch, desserts and appetizers. Make hot and tasty sandwiches, pancakes, fried eggs, pizza pockets and turnovers omelettes and more.

Hints

- For soft or liquid sandwich fillings use medium sliced bread, white or brown. If small amounts of filling use toasting read.
- Flavored butters may also be used.
- Suggested garnished for sandwiches, lettuce, parsley, mint, cress, stuffed olive halves, onions, tomatoes, etc.
- A teaspoon of sugar sprinkled on the outside makes toasted sandwiches crisper.

8. Veiller à ce que la poignée de fermeture soit bien fixée dans son logement.
   Durant l'opération de cuisson, le voyant vert s'allume et s'éteint afin que le thermostat puisse garder les grilles à la bonne température. Le sandwich sera cuit après 2, 3 minutes ou plus selon goût.
9. Ouvrir le couvercle et retirer le sandwich à l'aide d'un ustensile en bois ou en plastique adapté aux grilles anti-adhérentes.
10. Conserver le couvercle fermé pour préserver la chaleur jusqu'à la préparation du sandwich suivant.
11. Après utilisation débrancher l'appareil.

NB : Le sandwich toaster permet d'endurcir - au besoin - la partie supérieure de la nourriture et de cuire les viandes, volailles, fruits de mer et légumes. Il permet aussi de préparer rapidement les petits déjeûners, déjeûners, desserts et appéritifs (sandwichs, omelettes, pizzas...).

Conseils

- Pour des sandwichs légers, utiliser des tranches de pain fines ou du pain de mie.
- Pour un goût relevé, utiliser aussi les beurres épicés.
- Pour garnir les sandwichs, utiliser la laitue, le persil, la menthe, les olives dénoyautées, les oignons, les tomates, etc.
- Pour un effet craquant, saupoudrer de sucre la face extèrieure du sandwich .

CONSEILS D'ENTRETIEN

- Après utilisation et avant nettoyage débrancher l'appareil. Conserver l'appareil en position ouverte.
- Ne jamais plonger l'appareil dans l'eau. Nettoyer à l'aide d'une éponge humide et essuyer avec une serviette propre.
- Pour les taches difficiles, bien huiler les plaques et nettoyer après 5 minutes.
- Ne jamais gratter les particules brûlées avec un ustensile métallique pour ne pas endommager les plaques anti-adhérentes.
- Ne jamais nettoyer avec une éponge abrasive pour ne pas endommager l'appareil.

PRODUCT DESCRIPTION AND SKETCH

1. Control indicator lights
2. Anti-stick coated heating grills
3. Clip for opening and closing
4. Power cord storage

TECHNICAL CARACTERISTICS

Tension / Power : 220V-240V ~ 1400W

IMPORTANT SAFEGUARDS

- Make sure that the power supply meets the voltage marked on the label before power on the appliance.

- Read all instructions carefully.
- Do not touch hot surfaces during and after use. the appliance must be held by the handle.
- To protect against electrical shock, do not immerse cord, plug or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use or accessory attachements not recommended may cause fire, electric shock or injury.
- Do not use outdoors.
- Do not let cord hand over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- To disconnect, remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Never leave the appliance unattended during use.
- Any connection mistake of the appliance cancels the warranty.

HOW TO USE ...

1. When using for the first time, wipe the surface of the cooking plate with damp cloth and dry with cloth, tissue, etc.
2. Smear the cooking plate with butter, margarine or cooking fat.
3. Insert the mains plug into the wall socket.

- Lire attentivement toutes les instructions.
- Ne pas toucher les surfaces chaudes de l'appareil pendant et après utilisation, le manipuler par la poignée.
- Ne pas plonger l'appareil, la fiche ou le câble dans l'eau ou tout autre liquide, et ce, par protection contre les décharges électriques.
- Ne pas laisser les enfants ou les personnes handicapées manipuler l'appareil sans surveillance.
- Avant de procéder au nettoyage , débrancher l'appareil du réseau et le laisser refroidir.
- Ne pas utiliser l'appareil si le câble est endommagé.
- Ne pas utiliser d'accessoires ou d'ustensiles pouvant causés des dommages éléctriques ou autres.
- Ne pas exposer l'appareil aux agents atmosphériques (pluie, soleil,...)
- Ne pas laisser le câble pendre sur le bord de la surface où il repose.
- Ne placer l'appareil sur aucune surface chaude (plaque de cuisine, four...)
- Pour éteindre l'appareil débrancher le cordon d'alimentation.
- Ne pas utiliser l'appareil pour un usage autre que celui qui lui est destiné.
- Toute erreur de branchement ou de manipulation annule la garantie.

CONSEILS DE MISE EN MARCHE ET D'UTILISATION

1. Pour une 1ère utilisation, nettoyer les surfaces des grilles anti-adhérentes à l'aide d'un tissu humide et essuyer avec une serviette propre.
2. Huiler les grilles avec du beurre, de la margarine ou autre corps gras.
3. Brancher le cable d'alimentation.
4. Conserver l'appareil en position fermée pendant 5 minutes environ. Quant le voyant vert s'éteint, l'appareil est prêt à l'utilisation.
5. Ouvrir le couvercle et placer le sandwich sur la grille inférieure.
6. A l'aide des deux mains, exercer une pression sur le sandwich.
7. Fermer le couvercle soigneusement.

NB : - Ne pas forcer sur l'appareil lors de sa fermeture.
- Eviter le contact des mains avec la vapeur qui se dégage de l'appareil lors des opérations de cuisson.